

1) download the latest version of GMSH on: <http://gmsh.info/>

2) the mesh format use in ANA is older than the latest ones. We have to change it :

1. open gmsh
2. go to Help/Current Option and Workspace
3. write in the field "find" : Mesh.MshFileVersion
4. change the value at : 2.2
5. write in the field "find" : General.SaveOptions
6. change the value at : 1 (in order to keep this option in a next session of gmsh after closing it).